




## **Pro 700 video cable installation instructions**

<p>1. To install your new video harness, locate the white release tab on the side of the 26 pin AMP connector plugged into the Pro700™ display.</p>	
<p>2. Using a small flat blade screwdriver, push the tab in to release the sockets in the connector.</p>	
<p>3. The lock should be open now and will allow you to add the new wires to the connector. Note that the two small tabs now stick out of the connector on the opposite side of the large tab. Be careful not to pull any other wires out of the connector.</p>	
<p>4. Install your new harness by pushing the Video 2 wire socket all the way into hole number 8. Locate and push the Video 3 wire into hole number 16.</p>	<p>5. Once the sockets are pushed all the way in, slide the two small tabs back into place to lock the sockets in. Note all the sockets must be all the way into the connector before the tab will slide.</p>
<p>6. Plug the 26 pin AMP connector back into the Pro 700 and plug in the Video 1 connector onto the BNC connector.</p>	<p>7. Hook up the power lead to a ground (black) and switched power (red) supply. Your new harness is now ready for use.</p>