

NEW! 1910 Air Cart Primary Blockage Sensors




Part No. AE6705K

information and availability.


Have owners of the JD1910 air cart complained about primary tubes plugging and only finding out after the crop comes up that it happened? Now it can be monitored with a sensor available to fit on a newly designed 2.5" tube. Using the DICKEY-john® UniRate™ sensor and a new tube designed to hold the sensor, blockage or no flow through the primary tubes is a thing of the past. Primary sensor blockage can be added right to the SeedStar™ 2 blockage system with minimal installation. Call Ag Express for more



B6 on the screen shows the new member module added with 5 primary sensors



Pictured above are 3 of the primary sensors installed



Pictured is typical primary sensor harness layout for SS2; several sizes available.

6280 NE 14th Street
Des Moines, IA 50313
(515)289-2748 • Fax 289-2754
Corporate Office

106 W Main - Box 28
Sulphur Springs, IN 47388
(765)533-4809 • Fax 533-4688

308 Claude Rd
Grand Island, NE 68803
(308)381-2905 • Fax 381-4391